

TILE INSTALLATION

COMPATIBILITY

Dry Installation - Matte Tile, Resin Tile

Wet Installation - Matte Tile, Resin Tile

Outdoor Installation - All Tile with Exterior Finish

ACCLIMATION

Allow your Teak Tile five days to acclimate on location, before install.

This ensures minimal expansion and contraction.

CUTTING & DRILLING

You may use a wet saw with a sharp ceramic blade. Alternatively you can use a miter saw with a carbide blade. You may use standard woodworking drill bits for drilling.

INSTALLATION

- Ensure your substrate is clean, level & dry.
- Some acceptable substrates are cured concrete, cement backer-board or gypsum board.
- Distribute a thin-set mortar across your substrate.
- Place your Teak Tiles on the substrate.
- Allow the mortar to dry completely.
- Apply an epoxy grout between the tiles.
- Be sure to quickly clean off grout residue to prevent damaging the finish.

This document only provides product installation practices to assist customers in selecting, using, and installing our products. Customers' selection and usage of products are outside the direction and control of Indoteak Design and are completely and solely the responsibility of the customer. Indoteak Design does not warrant any product for any specific use, nor any installation procedure or maintenance practice.